

## Bore Gages

### Bore Gage Checker SERIES 515

- The Bore Gage Checker allows easy setting of dial bore gages with ranges of 18 mm (0.7 in) through 400 mm (16 in) using gauge blocks.
- Can be used in both vertical and horizontal positions.



515-590


### SPECIFICATIONS

Code No.	Applicable range	Flatness of parallel jaw	Parallelism of parallel jaw
515-590	18 - 400 mm (0.7 - 16 in)	0.5 $\mu$ m	1 $\mu$ m

### Measurement example



### Standard Accessories



- (1) Parallel jaw 2 pcs. **630030**
- (2) Attachment A **940088**
- (3) Attachment B **940089**
- (4) Attachment C **940090**