

Inside Micrometers

Tubular Inside Micrometers  
SERIES 137 — Extension-Rod Type (main unit)

- Micrometer head for Extension-rod Type inside micrometer.
- A reference gage is necessary for reference point setting.
- An optional reference gage, such as Gauge Block Accessory Set or a setting ring, is required for accurately setting the micrometer before measuring. (refer to pages 01-19 to 01-22 and 08-53 for details)



137-011

SPECIFICATIONS

Metric				
Code No.	Range (mm)	Spindle feed error* (μm)	Graduation (mm)	Micrometer head stroke (mm)
137-011	50 - 63	3	0.01	13
Carbide-tipped 137-013				

Inch				
Code No.	Range (in)	Spindle feed error* (in)	Graduation (in)	Micrometer head stroke (in)
137-012	2 - 2.5	0.00015	0.001	0.5
Carbide-tipped 137-014				

\* "Spindle feed error" refers to the difference between the maximum and minimum indication error values within the specification range of the micrometer head

DIMENSIONS

